


## The correct process for using the E-Cleaner is to:

1. First turn off the machine and unplug it.
2. Remove the filter from the machine and place the CPU (cleaning power unit) in the machine where the filter was.
3. Pour one packet of e-cleaner power into the CPU and close the top.
4. Put both hoses into a cup or pitcher.
5. Run the water until the ends of both hoses are submerged in water.
6. Let the machine soak for 5-8 hours or overnight.
7. Rinse the machine by running water for 10-15 minutes with the CPU still in place.
8. Stop the water and remove the CPU and put your filter back in.

(When storing your CPU don't store it wet with the lid on, allow it to completely dry.)

Even when you do e-cleanings regularly, you will still need to have a deep cleaning done at least once a year. This will ensure maximum effectiveness and yield the best results for your Kangen Water®.



## Bring your machine for Deep cleaning!

While it is important to clean your machine at home, it is also very important to schedule your machine for a deep cleaning. Your machine should have a deep cleaning once or twice a year. This will help ensure that it is running at peak performance and producing the very best and most effective water. **Deep cleaning is performed only at Enagic service centers\*.**

\*Please remove the enhancer tank before you bring or ship your machine to the service center. Please also remove the filter cover and diverter if possible.



**Enagic USA, Inc.** 4115 Spencer Street, Torrance, CA 90503 TEL: 310-542-7700 FAX: 310-347-4447

For inquiries regarding installation, maintenance and operation of product:

**Enagic Information Center Toll-Free: 1-866-261-9500**